



Lumi-Switch Instructions for SUPRA-Hubs

Note: EOS Hubs require the Lumi-Switch to have a connector. This connector is fitted as standard. To use with SUPRA-Hubs this connector will need to be removed.



SMX SUPRA-Hub



THX/TIX SUPRA-Hub



Lumi-Switch cable is required to be cut just behind the connector prior to installation. See diagram below for further information

